

Lock It For Love

Helping keep kids safe by providing free gun locks



Photo Credit: Grandparents Against Gun Violence, Kansas City, MO

Cable Gun Lock

How to use use a cable gun lock with various firearms:

- Revolver
- Pistol
- Shotgun
- Rifle




Using a Cable Gun Lock

For all firearms

Unload the firearm.

Open the lock by inserting the key and turning it clockwise.

Pull the cable out of the lock body.



Using a Cable Gun Lock

With a Revolver

Thread the cable through the barrel if possible.

If the cable isn't long enough there are two other possible methods.



Photo Credit: Grandparents Against Gun Violence, Kansas City, MO

Using a Cable Gun Lock

With a Revolver- two alternative methods

Thread the cable through two non-adjacent chambers in the cylinder. If the cylinder can be closed with the lock in place, reroute the cable.



Thread the cable around the frame.



Using a Cable Gun Lock

With a pistol

Thread the cable into the ejection port and out the empty magazine well.



Photo Credit: Grandparents Against Gun Violence, Kansas City, MO

Using a Cable Gun Lock

With a Shotgun

Thread the cable into the ejection port and out the loading port.



Photo Credit: Grandparents Against Gun Violence, Kansas City, MO

Using a Cable Gun Lock

With a Rifle

Thread the cable into the ejection port and out the loading port.



Photo Credit: Grandparents Against Gun Violence, Kansas City, MO

Using a Cable Gun Lock

For all firearms

Close and secure the lock on the firearm.

Store the key away from children.

